




RCA
unbal.



XLR
bal.



Use A Control software to reset internal parameters to factory default values

100-240 VAC
50/60 Hz



Switched-mode
Power Supply

Power-up
Mute



Treble



Midrange

A77H &
A8H only



Bass



Bass

A44H &
A77H only

A SERIES



ADAM AUDIO